


AVHzY CT-1 Quick Start Guide v1.75



-1-

Warning




It is a fatal mistake to operate the product as follows:

1. After high voltage triggered, the insertion of any device which has a maximum operating voltage below that high voltage may cause damage to the device plugged in.
2. When the power meter is monitoring the voltage & current on the two ports, DO NOT plug any device into the other ports, this will cause damage (Especially when the device being monitored required a high voltage) to the devices.

The author is not responsible for any result of a faulty operation.

-2-


Home Screen



Instruction page 4 for more detail.

-3-

Dynamic display curve



Press "R/+" to increase FPS volume
Press "L/-" to decrease FPS volume

Instruction page 28 for more detail. (P28)

-4-

Menu



Press "Enter"
and hold 3S


Press Twice

(P8)

Instruction page 8 for more detail.

-5-

FastCharge




Waiting 3S

(P14)

Instruction page 14 for more detail.

-6-

Clear group, Change screen direction, Test Cable Resistance



Press "R/+" and hold Switch direction of the screen

Press "L/ -" and hold 3S Test Cable Resistance (P25)

Press "R/+" and hold 3S Show the current Date, time, and temp

Instruction page 25 for more detail.

-7-

Technical Specifications

Main Control IC: STM32 F072

Display screen: TFT 1.44" 128*128

Voltage Current Range : 3.7-25V 0-5A

Voltage Current Resolution: 0.0001V 0.0001A

Voltage Current Accuracy: 0.1%+2d 0.1%+2d

Quiescent Current: 1mA

QC2.0 QC3.0 PD Trigger: Support

USB Firmware Update: Support

(P2)

Get Manual & Firmware from www.avhzy.com Support.

-8-